




Customer Service help.furniturechoice.co.uk

# - Thank you for buying the Grace 3 Seater Sofa



#### Before you start:

#### **Unpack carefully**

- Take care when unpacking and assembling your sofa as damaged or scratched items cannot be returned
- Do not use sharp objects
- Be careful not to dispose of the enclosed assembly kit
- Please retain all packaging until you are 100% happy with your sofa

#### Before and during assembly

- This sofa requires 2 people to assemble
- Make sure all items are accounted for and clearly laid out before starting
- Make sure you have enough space to assemble the sofa safely
- Assemble the sofa where it will be placed to avoid moving unnecessarily
- Place all parts on a soft and flat surface to avoid damage
- Make sure backrests are slotted in evenly and not at an angle
- Do not use power tools or overtighten any fittings as this can cause damage
- If the upholstery is creased, plump the cushions and allow the sofa to settle at room temperature
- Carefully trim off any loose threads

#### Caution


- Keep small parts, plastic bags and film away from children






■ 茶記 Customer Service help.furniturechoice.co.uk

# - In the box









Left Back Cushion

**x** 16




Bolt M8x25mm

**M** x 2



Flat Washer 22mm





**B** x 1

**F** x 1



**Right Back Cushion** 

**J** x 2



Bolt M8x30mm

**N** x 2





Flat Washer 30mm



Left Armrest








**Right Armrest** 

**H** x 1



Support Leg

**L** x 2



Spring Washer 12mm



Bolt M8x55mm

**K** x 2




Allen Key 5mm






■ 茶た回 Customer Service help.furniturechoice.co.uk

1 Tilt the armrests at a 75° angle and attach the seat to the armrests as shown, one at a time.



**2** Attach the feet and support leg to the sofa as shown.









■ 茶た回 Customer Service help.furniturechoice.co.uk


**3** Attach the backrest. With one person on each side, slot the backrest into the right and left brackets at the same time. Then push down evenly and firmly.



4 Secure the backrest to the seat as shown. Make sure the bolt holes on the seat and backrest are aligned.









help.furniturechoice.co.uk

**5** Attach the back cushions by removing the protective covers from the velcro strips.



6 Pat and plump the surfaces to reshape and align the cushions as necessary.






7



■ 批評 Customer Service help.furniturechoice.co.uk







# - Important information - please read before use



## Upholstery and appearance

- Every effort has been made to ensure each piece of furniture matches
- The materials used may have variation in colour and grain this is a natural characteristic of the material and not a fault
- If the upholstery is creased on delivery, allow it to settle at room temperature
- Creasing in seats and back cushions may appear over time this is a natural characteristic of the material and not a fault
- Upholstery can have a pile in the weave and look different from various angles and lighting this is a natural characteristic of the material and not a fault

#### **Cleaning your furniture**

- Do not use household cleaning products, bleaches, solvent based cleaners, detergents, corrosives, scourers or abrasives, which can damage surfaces and upholstery
- Dust and vacuum your furniture on a weekly basis with the appropriate upholstery attachment
- Use a clean, soft, lint-free cloth slightly dampened with water to remove dirt or body oils
- For tougher stains, use a soft cloth with a little non-alkaline, non-detergent soap

## Caring for your furniture

- Remove spills immediately do not rub stains and spills, blot them first
- Avoid placing damp clothing, wet towels or printed newspapers directly on the upholstery
- Avoid placing hot cups or plates directly onto the furniture as this can damage the upholstery
- Avoid strong sunlight (such as through patio doors and windows), as this can cause discolouration, fading or surface degradation over time
- Avoid strong sunlight on chrome finishes as this can magnify the heat of the sun
- Avoid sitting on the edge of the cushions as this can cause distortion or permanent wear
- Do not sit on the arms
- Avoid sharp objects such as studs, buckles, jewellery, heels, toys or a pet's claws on the upholstery as this can cause damage
- Greasy and oily hair products can damage upholstery
- Light-coloured upholstery can be at risk of discolouration due to dye transfer from dark or strong-coloured clothing, cushions and throws

#### Safety notes for recliners

- Ensure the footrest is returned correctly and the mechanism clicks back into place
- Do not put fingers down the side of the mechanism
- $-\operatorname{Do}\operatorname{not}\operatorname{sit}\operatorname{on}\operatorname{the}\operatorname{footrest}$

#### To avoid structural damage

- Do not stand or jump on the sofa
- Do not sit on the arms
- Do not drag the sofa when moving, instead lift and place carefully

This sofa is for indoor, residential use only.

### For more information and support, visit help.furniturechoice.co.uk